



ANALOG DISK

Introduction

Thank you for purchasing the Harmonic Resolution Systems (HRS) Analog Disk record clamp. When used properly, it will give you many years of superior musical signal reproduction. The HRS Analog Disk is designed to significantly reduce the negative impact of air and structure borne vibration on your record playback accuracy. The HRS Analog Disk is also a perfect match for the HRS Isolation Base. While the Analog Disk significantly reduces air-borne, record, and turntable generated vibration, the HRS Isolation Bases or Rack System significantly reduce the amount of structure-borne vibration that reaches the turntable from the surrounding environment.

Warnings:

The Analog Disk is designed for use on tangential arm turntables with a solid (non-threaded) spindle. When the record is finished playing the cartridge should not come in contact with the Analog Disk. Prior to use, the Analog Disk you should be checked to make sure there is no interference with your particular turntable configuration at the end of record play. If there is interference then the Analog Disk should not be used as it may result in undesired damage to the stylus or cartridge.

Use and Instructions

The Analog Disk is designed for use on tangential arm turntables with a solid (non-threaded) spindle. Check the fit of the center hole of the Analog Disk on your turntable spindle. It is intentionally design for a snug contact fit with the spindle. With a slight push and twist the custom polymer surface of the Analog Disk should come in direct contact with the album and remain in contact once pressure is removed. If you find that the Analog Disk grips your spindle then place a very small amount of dish soap or oil, using a Q-tip or tissue, at the entrance to the spindle hole in the Analog Disk. This will allow the Analog Disk to slide freely with slight pressure onto the spindle and establish proper contact with the record surface. Repeat lubrication as necessary to ensure optimum performance.

Care and Maintenance

The HRS Analog Disk is a very low maintenance item that will provide many years of trouble free performance by applying these basic care instructions.

Clean the Analog Disk using a lint-free soft (non-abrasive) cloth. Use a damp cloth with water or mild soap if required. Do not spray with or immerse in water.

Warnings!

Do not use an abrasive cleaner or abrasive sponge to clean the Nimbus, as they may scratch the metallic surface.

Do not wash with any solvent based cleaning solutions.

Warranty

Limited Five Year Warranty

Harmonic Resolution Systems warrants to the purchaser that Analog Disk is free of manufacturing defects for a period of five (5) years from the date of purchase. This warranty is subject to the following conditions and limitations.

- 1. A copy of the original purchase receipt from a certified Harmonic Resolution Systems authorized retailer is used to verify the date of original purchase and ownership.*
- 2. This warranty is void and inapplicable if the product has been handled other than in accordance with the instruction specified within this document, abuse or misused, damaged by accident or neglect or in being transported, or the defect is due to the product being tampered with, modified or repaired by anyone other than Harmonic Resolution Systems.*
- 3. Warranty does not cover normal recommended care and maintenance.*
- 4. Harmonic Resolution Systems shall not be responsible in any way for consequential or indirect damages or liabilities resulting from the use of the product covered herein or resulting from any breach of this warranty or any implied warranty relating to said product.*

During this period, Harmonic Resolution Systems will repair or replace any defective components free of charge. A Return Authorization Number (RA Number) is required before any product is returned to Harmonic Resolution Systems for any reason. This number must be visible on the exterior of the shipping container(s) for Harmonic Resolution Systems to accept the return.

Units shipped to Harmonic Resolution Systems without a visible RA Number on the exterior of the shipping container(s) are subject to be returned to the sender, freight collect.

Units to be repaired by Harmonic Resolution Systems must be sent shipping and insurance prepaid by the original purchaser in the original packaging material. A returned product should be accompanied by a written description of the defect. Repaired units will be returned by Harmonic Resolution System shipping and insurance prepaid.

All other warranties or conditions either written or implied are void.

HARMONIC RESOLUTION SYSTEMS INC.
Great Arrow Industrial Park
255 Great Arrow Ave, Suite 39A
Buffalo, NY 14207
Telephone: 716-873-1437
Web: www.avisolation.com
E-mail: info@avisolation.com